

Acacia Bistro Set Instruction Manual



After Sales Support
Call 0871 911 7031
Email
customerservice@gardengearonline.co.uk
Product Code G2856

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from date of purchase

For correct usage, please read these instructions carefully before use and keep in a safe place for future reference.



INTRODUCTION

Congratulations

You have made an excellent choice with the purchase of this quality Garden Gear product.

By doing so you now have the assurance and peace of mind which comes from purchasing a product that has been manufactured to the highest standards, performance and safety.

We want you to be completely satisfied with your purchase, so this Garden Gear product is backed by our full 12 month manufacturers guarantee and an outstanding after sales service through our dedicated Helpline.

Register your product for an extended 2-year warranty by visiting our website www.gardengearonline.co.uk. The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

We hope you enjoy using your purchase for many years to come.

General information and safety warnings

- Remove all packaging and make sure that the product is intact. Do not leave packaging materials like bags and staples within the reach of children and pets.
- Read through these instructions fully before using the product, it contains important information and must be retained for future reference. Read carefully.
- Regularly inspect the fixings for signs of wear.
- For outdoor use only.
- Do not stand on the furniture.
- Always use on a level surface.
- The maximum load weight for the table is 120kg.
- The maximum load weight for each chair is 120kg.
- Do not let children play on this furniture.
- Do not sit on the arms or back of this furniture.
- No more than 1 person should sit on 1 chair at any one time.
- Always store away the furniture if adverse weather is forecast or if not in use for long periods of time.
- Never drag the furniture. Always lift and move evenly between 2 people.
- Not suitable for commercial purposes.

Care and maintenance

- Your furniture will arrive pre-treated with oil to protect it from general outdoor use. However, we would recommend using a cover to protect from the elements, especially through autumn and winter.
- A seasonal cleaning may still be needed. Rinse the furniture and use a sponge or soft bristle brush to scrub the furniture with a mild cleaning solution. Lastly, rinse the furniture with fresh water; never soak or immerse the bench in water.
- To maintain the original finish, reapplication of a high-quality oil is recommended.
- Paint or any products containing polyurethane are not recommended.
- The cushions have removeable covers that can be washed on a 30°C cycle. Allow these to air dry. Do not tumble dry the covers.

Assembly

Simply unfold the chairs and the table.

GUARANTEE**IMPORTANT**

**Please do not return this product without first calling the Customer Service number below:
0871 911 7031***

Thank you for purchasing this product, which has been made to demanding high quality standards and is guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase.

Register your product for an extended 2-year warranty by visiting our website www.gardengearonline.co.uk. The product must be registered, along with your contact information, within 30 days of purchase. For full terms and conditions please visit our website.

This guarantee does not affect your statutory rights. If your product fails due to a defect in material or workmanship during this period, please return it to the place of purchase. Normal wear and tear is not covered under the guarantee.

Any guarantee is invalid if the product has been misused or subject to neglect or an attempted repair other than by our own service centre.

Due to continuous product improvement, we reserve the right to change the product specification without prior notice.

After Sales Customer Service:

Customer Service Department, Branded Garden Products Ltd, Premier House, Hortonwood 7, Telford, TF1 7GP, UK

Telephone: 0871 911 7031*

E-mail customerservice@gardengearonline.co.uk

Please retain for future reference.
Colours and contents may vary.

*Calls cost 13p per minute plus your phone company's access charge